



OLD TOWN RUDDER

TOOLS NEEDED

- Wire
- Wire Cutters
- Philips head screw driver
- Allen Wrench

ASSEMBLY & INSTALLATION INSTRUCTIONS

1. Remove factory rudder, bushings and cap screws (Note: Before taking the factory rudder apart, make sure you know what line is Running Rudder Direction, due to how Old Town Rudder will set it up.)

2. Place the Bored Bushing and Tapped Bushing on either side of the rudder matching up the holes.

3. Place the bolts through the Bored Bushing's recessed holes and tighten through the rudder and out of the Tapped Bushing (DO NOT OVERTIGHTEN)

4. Place Rudder handle in down position. Left side cable and rudder should be loose. Right side should be tight.

5. Handle the two Screws on lever. (Left is left rudder, Right is right rudder)

6. Place Rudder handle in down position.

7. Take the knot out of line on handle. Do not cut!

8. Loosen bolt, go to back, and pull slight.

9. Go to rudder and take bolt out of rudder housing.

10. Follow how the rudder line is on the rudder. Do not cut line, just loosen the line.

11. Notch on the bottom.

12. Thread line as it is on the factory.

13. Place back with housing and tighten bolt and screw.



PARTS LIST

A- Rudder Blade - 1



B- Bored Bushing - 1



C- Tapped Bushing - 1



D- SOC HD Cap Screw
10-24 x .5625 - 2



E- Warranty

